

# **K-Lever 2 Installation Instructions**

## **Harley Davidson FLHR Models**

*This installation should ONLY be performed by a Professional.  
Serious injury or death may occur if not installed properly.*

Remove the Right Floorboard Assembly, set aside with Mounting Hardware. Remove the Rear Brake Pedal and Master Cylinder Assembly. Install the Short Rubber Hose supplied onto the Rear Brake Pedal Pivot Shaft and secure with the original nut. Reinstall the Right Floor Board Assembly. Install the Brake Hose onto the Rear Brake Line Banjo Fitting. The Fitting and Hose Assembly will now be pointed forward. Using the Fitting and Hose Assembly for leverage, *carefully rotate* it *UP* 90 Degrees along the Right Side Frame Down Tube.

Remove Headlight & Nacelle: **Disconnect** the **Blue/Red Wire** at the Black Connector from the Right Handle Bar Switch. (Front Brake Light)

*Note: Mechanics Disconnect, Butchers Cut.*

Disconnect and remove the original Front Brake Master Cylinder Assembly. Leave the Original Front Brake Line it will be attached to the K-Lever 2 using the Banjo Bolts and Crush Washers supplied. Install the K-Lever 2 onto the Handle Bars. Place the Reservoir Hose between the Handle Bar and the K-Lever 2. Position the Reservoir bottom flush with the K-Lever 2 top, secure in place. Attach original Front Brake line onto the K-Lever 2. Route the SS Hose up the Right Side Frame Down Tube, under the Main Wire Harness, then in Front of the Top Triple Tree, and out the Nacelle along with the Front Brake Line. Install the SS Braided Brake Hose Assembly supplied to the K-Lever 2. Reinstall Headlight & Nacelle.

*Note: On Trikes the Top Lever S/B the Rear Brake*

**Bleed the Front Brakes. Bleed the Rear Brakes. Check for leaks.**

### **TEST RIDE**

Make sure Front & Rear Brakes work properly. Adjust Lever Positions.

**Recheck and Confirm all connections are tight.  
Confirm Brake Light operation.**



**SO CAL TRIKE CENTER  
BIKES, TRIKES, TRAILERS AND SIDECARS  
1-800-649-4749**





**On Trikes the Top Lever should be the Rear Brake**





**Shown with Residual Valve  
which is Only used on Trikes**

**SO CAL TRIKE CENTER  
BIKES, TRIKES, TRAILERS AND SIDECARS  
1-800-649-4749**